



TRACOM WEIR BOX INSTALLATION INSTRUCTIONS

1. Follow all instructions provided by the project engineers in the form of specifications, blue prints, etc.
2. If used, verify that the concrete pad is free of debris, true to plane, and of the correct dimensions to receive the structure. Correct all deficiencies before proceeding.
3. Connect the flexible neoprene boots to the inlet and outlet PVC weir box pipe stubs (if pipe stubs are provided).
4. The notched weir plate end should be set downstream.
5. Set the structure and level from inlet to outlet and from side to side. The structure walls must be vertically plumb.
6. Connect the flexible neoprene boots to the existing inlet and outlet pipe (if pipe stubs are provided).