



TRACOM EQUIPMENT MOUNTING PANEL INSTALLATION INSTRUCTIONS

1. Follow all instructions provided by the project engineers in the form of specifications, blue prints, etc.
2. Verify that the concrete pad is free of debris, level, true to plane, and of the correct dimensions to receive the structure. Correct all deficiencies before proceeding.
3. Move and position the equipment mounting panel into place.
4. Layout the anchor bolt pattern according to the engineer's specifications. Drill and set the anchor bolts starting with one corner and then drilling and setting the bolt diagonally across from it. Drill the anchor bolt holes to the depth and diameter required by the anchor bolt manufacturer. Wedge style concrete anchors (1/2" x 4-1/2") are recommended.
5. The anchor bolts should be installed in those areas predrilled by the factory and per the engineer's specifications.
6. Seal the floor penetrations with silicone caulk.

Date: 10/7/2002
By: Matt Kazmier