



EQUIPMENT MOUNTING PANEL INSTALLATION INSTRUCTIONS

1. Follow all instructions provided by the project engineers in the form of specifications, blue prints, etc.
2. Verify that the concrete pad is free of debris, level, true to plane, and of the correct dimensions to receive the structure. Correct all deficiencies before proceeding.
3. Move and position the equipment mounting panel into place.
4. Layout the anchor bolt pattern according to the engineer's specifications.
5. Stainless steel wedge style concrete anchors are recommended. Anchors should be a minimum of 1/2 inch (1,27 cm) diameter x 4-1/2 inch (11,43 cm) long. TRACOM does not recommend the use of pre-set anchor bolts. Anchor bolts are to be supplied by others.
6. The anchor bolts should be installed on maximum center spacing of 24" or as per the engineer's specifications.
7. Seal the mounting flange penetrations with urethane caulk.

Document: EQMT-I
Revision: 0
Date: 8-9-04
By: Matt Kazmier